# Swann
Security Made Smarter

Smart Home
Key Fob

At a Glance

Thank you for choosing the **Smart Home Key Fob**. The **Smart Home Key Fob** allows you to activate Home, Away and Night modes without the need for a smartphone.

Status LED

Home Button

Away Button

Night Button

Panic Button
Send an emergency alert notification to people on your contact list if you require assistance

Key Ring
IMPORTANT: Always install the key ring as it is designed to secure the back cover in place and prevent children accessing the coin/button cell battery

Compliance Information

FCC Statement This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

CE marking on this product represents the product is in compliance with all directives that are applicable to it.

Correct Disposal of this product. This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environment safe recycling.

Battery Safety Information

- This product contains a coin/button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death. Keep away from babies and small children at all times. As a child safety precaution, always attach the included key ring to secure the back cover and prevent access to the battery.
- If battery is swallowed or placed inside any part of the body, immediately seek medical help.
- Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries promptly in accordance with local regulations.

Need Help?

|			
USA & Canada	1800 627 2799	Australia	1800 788 210
UK & Europe	0808 168 9031	New Zealand	0800 479 266

tech@swann.com

support.swann.com

SMARTHOME-KFVER1E

© Swann Communications 2018

Activating the Key Fob

1. Slide the back cover off.

2. Pull out the protective strip to engage the battery and activate the Key Fob.


Protective Strip

IMPORTANT: Make sure to replace the key ring once you have finished setting up the Key Fob.

Pairing the Key Fob

1. From the Smart Home web portal, click or tap **My Settings > Key Fobs > add device**. The System Setup screen is displayed and your Smart DVR/Hub automatically goes into pairing mode.

   Note: You can skip this step if the System Setup screen is already displayed (during the Smart DVR/Hub registration process, or when you are setting up other smart home accessories).

2. Press the **Connect** button on the Key Fob. The status LED blinks once. When the Key Fob has paired with your Smart DVR/Hub, the status LED blinks twice.

Connect Button

3. Follow the on-screen instructions to complete the setup.

How it works?

The Key Fob works as a remote control within your Smart Home system, offering a quick and convenient way for you to activate a particular security mode whether you are staying, leaving or arriving home.

Arming your system with the Key Fob

Double-press the **Away** or **Night** button to arm your Smart Home system in Away or Night mode. The LED blinks green and then red twice for Night mode and thrice for Away mode as confirmation. There is a entry/exit delay period which allows you enter, leave or walk freely around the inside of the premises, before your system is active in Away or Night mode. The default entry/exit delay period is 20 seconds. You can easily configure the **Entry/Exit Delay** period from the Smart Home web portal via **My Settings > Smart Hub**.

Disarming your system with the Key Fob

Double-press the **Home** button to disarm your Smart Home system. The LED blinks green and then red as confirmation.

*Tip: Have a Smart Home Siren accessory connected? Simply use the Key Fob to immediately turn off the alarm by double-pressing the **Home** button.*

Troubleshooting

The Key Fob is not pairing with my Smart DVR/Hub

Reset the Key Fob - press and hold the Connect button until the status LED blinks rapidly. Then, try pairing the Key Fob again.

The Key Fob is not working. The Status LED does not light up when I double-press any of the Home, Away or Night buttons

The Key Fob is running low on battery power. Replace the battery in the Key Fob with one fresh "CR2032" lithium battery immediately.